GREENTEETH® SHARPENING GUIDE

 Greenteeth®

Sharpen your Greenteeth® when:

- The tooth has worn approximately 1/16th of an inch around all edges. (Figure 1.1)
- Production is noticeably reduced.

Sharpening intervals:

- **Greenteeth**® can be sharpened to a minimum of 1/8" (.125") carbide thickness or ¼" (.250) as measured from the top of the carbide down to the steel shank flat. (Figure 1.2)
- **Greenteeth**® may be sharpened up to 3 times depending on how severe the cutting edges are worn prior to removal.





WWW.GREENTEETH.COM

©2025 Green Manufacturing, Inc.